



**Hadron Xtorm Series**  
**IEC 60870-5-104**  
**Client**  
**Device Profile**

Rev. A 05/2022

Doc. Code.: MU223604



**altus**

[www.altus.com.br](http://www.altus.com.br)

---



No part of this document may be copied or reproduced in any form without the prior written consent of Altus Sistemas de Automação S.A. who reserves the right to carry out alterations without prior advice.

According to current legislation in Brazil, the Consumer Defense Code, we are giving the following information to clients who use our products, regarding personal safety and premises.

The industrial automation equipment, manufactured by Altus, is strong and reliable due to the stringent quality control it is subjected to. However, any electronic industrial control equipment (programmable controllers, numerical commands, etc.) can damage machines or processes controlled by them when there are defective components and/or when a programming or installation error occurs. This can even put human lives at risk.

The user should consider the possible consequences of the defects and should provide additional external installations for safety reasons. This concern is higher when in initial commissioning and testing.

The equipment manufactured by Altus does not directly expose the environment to hazards, since they do not issue any kind of pollutant during their use. However, concerning the disposal of equipment, it is important to point out that built-in electronics may contain materials which are harmful to nature when improperly discarded. Therefore, it is recommended that whenever discarding this type of product, it should be forwarded to recycling plants, which guarantee proper waste management.

It is essential to read and understand the product documentation, such as manuals and technical characteristics before its installation or use.

The examples and figures presented in this document are solely for illustrative purposes. Due to possible upgrades and improvements that the products may present, Altus assumes no responsibility for the use of these examples and figures in real applications. They should only be used to assist user trainings and improve experience with the products and their features.

Altus warrants its equipment as described in General Conditions of Supply, attached to the commercial proposals.

Altus guarantees that their equipment works in accordance with the clear instructions contained in their manuals and/or technical characteristics, not guaranteeing the success of any particular type of application of the equipment.

Altus does not acknowledge any other guarantee, directly or implied, mainly when end customers are dealing with third-party suppliers.

The requests for additional information about the supply, equipment features and/or any other Altus services must be made in writing form. Altus is not responsible for supplying information about its equipment without formal request.

These products use EtherCAT® technology ([www.ethercat.org](http://www.ethercat.org)).

## **COPYRIGHTS**

Nexto, Ponto Series, MasterTool, Grano and WebPLC are the registered trademarks of

Altus Sistemas de Automação S.A.

*Windows, Windows NT and Windows Vista* are registered trademarks of Microsoft Corporation.

## **OPEN SOURCE SOFTWARE NOTICE**

To obtain the source code under GPL, LGPL, MPL and other open source licenses, that is contained in this product, please contact [opensource@altus.com.br](mailto:opensource@altus.com.br). In addition to the source code, all referred license terms, warranty disclaimers and copyright notices may be disclosed under request.

---

---

## DEVICE PROFILE REVISION HISTORY

<b>Date</b>	<b>Revision</b>	<b>Reason for change</b>	<b>Edited by</b>
05/02/2022	A	First edition.	Osmar Brune

---

---

## Interoperability IEC 60870-5-104

### System or device

(system-specific parameter, indicate the station's function by marking one of the following with 'X')

- System definition
- Controlling station definition (Master)
- Controlled station definition (Slave)

### Network configuration

( Not Applicable )

### Physical layer

( Not Applicable )

### Link layer

( Not Applicable )

### Application layer

#### Transmission mode for application data

Mode 1 (Least significant octet first), as defined in clause 4.10 of IEC 60870-5-4, is used exclusively in this companion standard.

#### Common address of ASDU

(system-specific parameter, all configurations that are used are to be marked 'X')

- One octet
- Two octets

#### Information object address

(system-specific parameter, all configurations that are used are to be marked 'X')

- One octet
- Two octets
- Three octets
- Structured
- Unstructured

#### Cause of transmission

(system-specific parameter, all configurations that are used are to be marked 'X')

- One octet
- Two octets (with originator address)  
Originator address is set to zero if not used

---

## Length of APDU

(system-specific parameter, specify the maximum length of the APDU per system)

The maximum length of APDU for both directions is 253. It is a fixed system parameter.

<input type="checkbox"/>	Maximum length of APDU per system in control direction
<input type="checkbox"/>	Maximum length of APDU per system in monitor direction

## Selection of standard ASDUs

### Process information in monitor direction

(station-specific parameter, mark each Type ID 'X' if it is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

<input checked="" type="checkbox"/>	<1> := Single-point information	M_SP_NA_1
<input type="checkbox"/>	<2> := Single-point information with time tag	M_SP_TA_1
<input checked="" type="checkbox"/>	<3> := Double-point information	M_DP_NA_1
<input type="checkbox"/>	<4> := Double-point information with time tag	M_DP_TA_1
<input checked="" type="checkbox"/>	<5> := Step position information	M_ST_NA_1
<input type="checkbox"/>	<6> := Step position information with time tag	M_ST_TA_1
<input type="checkbox"/>	<7> := Bitstring of 32 bit	M_BO_NA_1
<input type="checkbox"/>	<8> := Bitstring of 32 bit with time tag	M_BO_TA_1
<input checked="" type="checkbox"/>	<9> := Measured value, normalized value	M_ME_NA_1
<input type="checkbox"/>	<10> := Measured value, normalized value with time tag	M_ME_TA_1
<input checked="" type="checkbox"/>	<11> := Measured value, scaled value	M_ME_NB_1
<input type="checkbox"/>	<12> := Measured value, scaled value with time tag	M_ME_TB_1
<input checked="" type="checkbox"/>	<13> := Measured value, short floating point value	M_ME_NC_1
<input type="checkbox"/>	<14> := Measured value, short floating point value with time tag	M_ME_TC_1
<input checked="" type="checkbox"/>	<15> := Integrated totals	M_IT_NA_1
<input type="checkbox"/>	<16> := Integrated totals with time tag	M_IT_TA_1
<input type="checkbox"/>	<17> := Event of protection equipment with time tag	M_EP_TA_1
<input type="checkbox"/>	<18> := Packed start events of protection equipment with time tag	M_EP_TB_1
<input type="checkbox"/>	<19> := Packed output circuit information of protection equipment with time tag	M_EP_TC_1
<input type="checkbox"/>	<20> := Packed single-point information with status change detection	M_SP_NA_1
<input type="checkbox"/>	<21> := Measured value, normalized value without quality descriptor	M_ME_ND_1
<input checked="" type="checkbox"/>	<30> := Single-point information with time tag CP56Time2a	M_SP_TB_1
<input checked="" type="checkbox"/>	<31> := Double-point information with time tag CP56Time2a	M_DP_TB_1
<input checked="" type="checkbox"/>	<32> := Step position information with time tag CP56Time2a	M_ST_TB_1
<input type="checkbox"/>	<33> := Bitstring of 32 bit with time tag CP56Time2a	M_BO_TB_1
<input checked="" type="checkbox"/>	<34> := Measured value, normalized value with time tag CP56Time2a	M_ME_TD_1

<input checked="" type="checkbox"/>	<35> := Measured value, scaled value with time tag CP56Time2a	M_ME_TE_1
<input checked="" type="checkbox"/>	<36> := Measured value, short floating point value with time tag CP56Time2a	M_ME_TF_1
<input checked="" type="checkbox"/>	<37> := Integrated totals with time tag CP56Time2a	M_IT_TB_1
<input type="checkbox"/>	<38> := Event of protection equipment with time tag CP56Time2a	M_EP_TD_1
<input type="checkbox"/>	<39> := Packed start events of protection equipment with time tag CP56Time2a	M_EP_TE_1
<input type="checkbox"/>	<40> := Packed output circuit information of protection equipment with time tag CP56Time2a	M_EP_TF_1

In this companion standard only the use of the set <30> – <40> for ASDUs with time tag is permitted.

### Process information in control direction

(station-specific parameter, mark each Type ID 'X' if it is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

<input checked="" type="checkbox"/>	<45> := Single command	C_SC_NA_1
<input checked="" type="checkbox"/>	<46> := Double command	C_DC_NA_1
<input checked="" type="checkbox"/>	<47> := Regulating step command	C_RC_NA_1
<input checked="" type="checkbox"/>	<48> := Set point command, normalized value	C_SE_NA_1
<input checked="" type="checkbox"/>	<49> := Set point command, scaled value	C_SE_NB_1
<input checked="" type="checkbox"/>	<50> := Set point command, short floating point value	C_SE_NC_1
<input type="checkbox"/>	<51> := Bitstring of 32 bit	C_BO_NA_1
<input type="checkbox"/>	<58> := Single command with time tag CP56Time 2a	C_SC_TA_1
<input type="checkbox"/>	<59> := Double command with time tag CP56Time 2a	C_DC_TA_1
<input type="checkbox"/>	<60> := Regulating step command with time tag CP56Time 2a	C_RC_TA_1
<input type="checkbox"/>	<61> := Set point command, normalized value with time tag CP56Time 2a	C_SE_TA_1
<input type="checkbox"/>	<62> := Set point command, scaled value with time tag CP56Time 2a	C_SE_TB_1
<input type="checkbox"/>	<63> := Set point command, short floating point value with time tag CP56Time 2a	C_SE_TC_1
<input type="checkbox"/>	<64> := Bitstring of 32 bit with time tag CP56Time 2a	C_BO_TA_1

Either the ASDUs of the set <45> – <51> or of the set <58> – <64> are used.

### System information in monitor direction

(station-specific parameter, mark with an "X" if it is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).

<input checked="" type="checkbox"/>	<70> := End of initialization	M_EI_NA_1
-------------------------------------	-------------------------------	-----------

### System information in control direction

(station-specific parameter, mark each Type ID 'X' if it is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

<input checked="" type="checkbox"/>	<100>:= Interrogation command	C_IC_NA_1
-------------------------------------	-------------------------------	-----------

---

<input checked="" type="checkbox"/>	<101>:= Counter interrogation command	C_CI_NA_1
<input type="checkbox"/>	<102>:= Read command	C_RD_NA_1
<input checked="" type="checkbox"/>	<103>:= Clock synchronization command (option see 7.6)	C_CS_NA_1
<input type="checkbox"/>	<104>:= Test command	C_TS_NA_1
<input checked="" type="checkbox"/>	<105>:= Reset process command	C_RP_NA_1
<input type="checkbox"/>	<106>:= Delay acquisition command	C_CD_NA_1
<input type="checkbox"/>	<107>:= Test command with time tag CP56time2a	C_TS_TA_1

### Parameter in control direction

(station-specific parameter, mark each Type ID 'X' if it is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

<input type="checkbox"/>	<110>:= Parameter of measured value, normalized value	P_ME_NA_1
<input type="checkbox"/>	<111>:= Parameter of measured value, scaled value	P_ME_NB_1
<input type="checkbox"/>	<112>:= Parameter of measured value, short floating point value	P_ME_NC_1
<input type="checkbox"/>	<113>:= Parameter activation	P_AC_NA_1

### File Transfer

(station-specific parameter, mark each Type ID 'X' if it is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

<input type="checkbox"/>	<120>:= File ready	F_FR_NA_1
<input type="checkbox"/>	<121>:= Section ready	F_SR_NA_1
<input type="checkbox"/>	<122>:= Call directory, select file, call file, call section	F_SC_NA_1
<input type="checkbox"/>	<123>:= Last section, last segment	F_LS_NA_1
<input type="checkbox"/>	<124>:= Ack file, ack section	F_AF_NA_1
<input type="checkbox"/>	<125>:= Segment	F_SG_NA_1
<input type="checkbox"/>	<126>:= Directory {blank or X, only available in monitor (standard) direction}	F_DR_TA_1
<input type="checkbox"/>	<127>:= Query Log – Request archive file	F_SC_NB_1

### Type identifier and cause of transmission assignments

(station-specific parameters)

'X' if only used in the standard direction

'R' if only used in the reverse direction

'B' if used in both directions



Type identification		Cause of transmission																		
		periodic, cyclic	background scan	spontaneous	initialized	request or requested	activation	activation confirmation	deactivation	deactivation confirmation	activation termination	return info caused by a remote cmd	return info caused by a local cmd	file transfer	interrogated by group <number>	request by group <n> counter request	unknown type identification	unknown cause of transmission	unknown common address of ASDU	unknown information object address
		1	2	3	4	5	6	7	8	9	10	11	12	13	20 to 36	37 to 41	44	45	46	47
<1>	M_SP_NA_1											X			X					
<2>	M_SP_TA_4																			
<3>	M_DP_NA_1											X			X					
<4>	M_DP_TA_4																			
<5>	M_ST_NA_1											X			X					
<6>	M_ST_TA_4																			
<7>	M_BO_NA_1																			
<8>	M_BO_TA_4																			
<9>	M_ME_NA_1															X				
<10>	M_ME_TA_4																			
<11>	M_ME_NB_1															X				
<12>	M_ME_TB_4																			
<13>	M_ME_NC_1															X				
<14>	M_ME_TC_4																			
<15>	M_IT_NA_1																X			
<16>	M_IT_TA_4																			
<17>	M_EP_TA_4																			
<18>	M_EP_TB_4																			
<19>	M_EP_TC_4																			
<20>	M_PS_NA_1																			
<21>	M_ME_ND_1																			
<30>	M_SP_TB_1			X																
<31>	M_DP_TB_1			X																

Type identification		Cause of transmission																			
		periodic, cyclic	background scan	spontaneous	initialized	request or requested	activation	activation confirmation	deactivation	deactivation confirmation	activation termination	return info caused by a remote cmd	return info caused by a local cmd	file transfer	interrogated by group <number>	request by group <n> counter request	unknown type identification	unknown cause of transmission	unknown common address of ASDU	unknown information object address	
		1	2	3	4	5	6	7	8	9	10	11	12	13	20 to 36	37 to 41	44	45	46	47	
<32>	M_ST_TB_1			X																	
<33>	M_BO_TB_1																				
<34>	M_ME_TD_1			X																	
<35>	M_ME_TE_1			X																	
<36>	M_ME_TF_1			X																	
<37>	M_IT_TB_1			X												X					
<38>	M_EP_TD_1																				
<39>	M_EP_TE_1																				
<40>	M_EP_TF_1																				
<45>	C_SC_NA_1						X	X	X	X	X						X	X	X	X	
<46>	C_DC_NA_1						X	X	X	X	X						X	X	X	X	
<47>	C_RC_NA_1						X	X	X	X	X						X	X	X	X	
<48>	C_SE_NA_1						X	X	X	X	X						X	X	X	X	
<49>	C_SE_NB_1						X	X	X	X	X						X	X	X	X	
<50>	C_SE_NC_1						X	X	X	X	X						X	X	X	X	
<51>	C_BO_NA_1																				
<58>	C_SC_TA_1																				
<59>	C_DC_TA_1																				
<60>	C_RC_TA_1																				
<61>	C_SE_TA_1																				
<62>	C_SE_TB_1																				
<63>	C_SE_TC_1																				
<64>	C_BO_TA_1																				
<70>	M_EI_NA_1*				X																
<100>	C_IC_NA_1						X	X	X	X	X						X	X	X	X	

Type identification		Cause of transmission																		
		periodic, cyclic	background scan	spontaneous	initialized	request or requested	activation	activation confirmation	deactivation	deactivation confirmation	activation termination	return info caused by a remote cmd	return info caused by a local cmd	file transfer	interrogated by group <number>	request by group <n> counter request	unknown type identification	unknown cause of transmission	unknown common address of ASDU	unknown information object address
		1	2	3	4	5	6	7	8	9	10	11	12	13	20 to 36	37 to 41	44	45	46	47
<101>	C_CI_NA_1						X	X			X						X	X	X	X
<102>	C_RD_NA_1																			
<103>	C_CS_NA_1						X	X									X	X	X	X
<104>	C_TS_NA_4																			
<105>	C_RP_NA_1						X	X									X	X	X	X
<106>	G_CD_NA_4																			
<107>	C_TS_TA_1																			
<110>	P_ME_NA_1																			
<111>	P_ME_NB_1																			
<112>	P_ME_NC_1																			
<113>	P_AC_NA_1																			
<120>	F_FR_NA_1																			
<121>	F_SR_NA_1																			
<122>	F_SC_NA_1																			
<123>	F_LS_NA_1																			
<124>	F_AF_NA_1																			
<125>	F_SG_NA_1																			
<126>	F_DR_TA_1*																			
<127>	F_SC_NB_1*																			

\* Blank or X only

---

## Basic application functions

### Station initialization

(station-specific parameter, mark 'X' if function is used)

Remote initialization

### Cyclic data transmission

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

Cyclic data transmission

### Read procedure

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

Read procedure

### Spontaneous transmission

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

Spontaneous transmission

### Double transmission of information objects with cause of transmission spontaneous

(station-specific parameter, mark each information type 'X' where both a Type ID without time and corresponding Type ID with time are issued in response to a single spontaneous change of a monitored object)

The following type identifications may be transmitted in succession caused by a single status change of an information object. The particular information object addresses for which double transmission is enabled are defined in a project-specific list.

- Single-point information M\_SP\_NA\_1, M\_SP\_TA\_1, M\_SP\_TB\_1 and M\_PS\_NA\_1
- Double-point information M\_DP\_NA\_1, M\_DP\_TA\_1 and M\_DP\_TB\_1
- Step position information M\_ST\_NA\_1, M\_ST\_TA\_1 and M\_ST\_TB\_1
- Bitstring of 32 bit M\_BO\_NA\_1, M\_BO\_TA\_1 and M\_BO\_TB\_1 (if defined for a specific project)
- Measured value, normalized value M\_ME\_NA\_1, M\_ME\_TA\_1, M\_ME\_ND\_1 and M\_ME\_TD\_1
- Measured value, scaled value M\_ME\_NB\_1, M\_ME\_TB\_1 and M\_ME\_TE\_1
- Measured value, short floating point number M\_ME\_NC\_1, M\_ME\_TC\_1 and M\_ME\_TF\_1

---

### Transmission Mode of Analog Events

(station-specific parameter, mark 'X' if function is used)

- SOE
- Most Recent Event

### Station interrogation

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

- global
  - group 1
  - group 2
  - group 3
  - group 4
  - group 5
  - group 6
  - group 7
  - group 8
  - group 9
  - group 10
  - group 11
  - group 12
  - group 13
  - group 14
  - group 15
  - group 16
- Information Object Addresses assigned to each group must be shown in a separate table

### Clock synchronization

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

- Clock synchronization
- Day of week used
- RES1, GEN (time tag substituted/ not substituted) used
- SU-bit (summertime) used

optional, see 7.6

### Command transmission

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

- Direct command transmission
- Direct set point command transmission
- Select and execute command
- Select and execute set point command
- C\_SE ACTTERM used

- 
- No additional definition
  - Short pulse duration (duration determined by a system parameter in the outstation)
  - Long pulse duration (duration determined by a system parameter in the outstation)
  - Persistent output
  
  - Supervision of maximum delay in command direction of commands and set point commands

### Transmission of integrated totals

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

- Mode A: Local freeze with spontaneous transmission
- Mode B: Local freeze with counter interrogation
- Mode C: Freeze and transmit by counter-interrogation commands
- Mode D: Freeze by counter-interrogation command, frozen values reported spontaneously

- Counter read
- Counter freeze without reset
- Counter freeze with reset
- Counter reset

- General request counter
- Request counter group 1
- Request counter group 2
- Request counter group 3
- Request counter group 4

### Parameter loading

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

- Threshold value
- Smoothing factor
- Low limit for transmission of measured values
- High limit for transmission of measured values

---

**Parameter activation**

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

Act/deact of persistent cyclic or periodic transmission of the addressed object

**Test procedure**

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

Test procedure

**File transfer**

(station-specific parameter, mark 'X' if function is used)

File transfer in monitor direction

- Transparent file
- Transmission of disturbance data of protection equipment
- Transmission of sequences of events
- Transmission of sequences of recorded analog values

File transfer in control direction

Transparent file

**Background scan**

(station-specific parameter, mark 'X' if function is only used in the standard direction, 'R' if only used in the reverse direction, and 'B' if used in both directions)

Background scan

**Acquisition of transmission delay**

(Not Applicable)

---

### Definition of time outs

Parameter	Default value	Remarks	Selected value
$t_0$	30s	Time-out of connection establishment	<b>Not Configurable</b>
$t_1$	15s	Time-out of send or test APDUs	<b>Configurable</b>
$t_2$	10s	Time-out for acknowledges in case of no data messages $t_2 < t_1$	<b>Configurable</b>
$t_3$	20s	Time-out for sending test frames in case of a long idle state	<b>Configurable</b>

Maximum range of values for all time outs: 1 to 180 s, accuracy 1 s

### Maximum number of outstanding I format APDUs $k$ and latest acknowledge APDUs ( $w$ )

Parameter	Default value	Remarks	Selected value
$k$	12 APDUs	Maximum difference receive sequence number to send state variable	<b>Configurable</b>
$w$	8 APDUs	Latest acknowledge after receiving $w$ I-format APDUs	<b>Configurable</b>

Maximum range of values  $k$ : 1 to 12 APDUs, accuracy 1 APDU

Maximum range of values  $w$ : 1 to 8 APDUs, accuracy 1 APDU (Recommendation:  $w$  should not exceed two-thirds of  $k$ ).

### Portnumber

Parameter	Value	Remarks
Portnumber	2404	In all cases



---

### **RFC 2200 suite**

RFC 2200 is an official Internet Standard which describes the state of standardization of protocols used in the Internet as determined by the Internet Architecture Board (IAB). It offers a broad spectrum of actual standards used in the Internet. The suitable selection of documents from RFC 2200 defined in this standard for given projects has to be chosen by the user of this standard.

- Ethernet 802.3
- Serial X.21 interface
- Other selection from RFC 2200